


DSR16 file load instructions


Down load “DSR16 new CH list 14.06.16.udf” file onto flash drive. Insert into DSR16 with USB cable supplied with DSR16



Push menu and select System Setup



Scroll down to Sotdware-Update



Pin code 0000



- Upgrade By USB
- Save Channel List
- Load Channel List

Load Channel list

Update Mode userdb
Upgrade File DB00.UDF
Start

0%

UDF file will appear

Update Mode userdb
Upgrade File DB00.UDF
Start

100%

Are you sure to burn flash?

Yes

No

Select YES, it will load the file and reboot the DSR16